

## Factory Reset on the Sony HDW-F500 HDCAM

- Press: **Home** Button
- Press: **Set Up** Button
- Press: **F1** (VTR BANK)
- Using Arrows: Scroll **Down** to **F** (PRESET)
- Press: **F9** (COPY)
- Press: **SFT & F9** Simultaneously
- Press: **Home** Button