

## Setting Time-Code on the Sony SRW-5500 HDCAM-SR

- **Press: Home** button
- **Press: TC** button
- **Set F1 to TC**
- **Set F5 to Ltc or Vitc**
- **Set F6 to int (L or V)**  
\*Note: F7 needs to be on "Regen" to change F6
- **Set F7 to preset**
- **Set F8 to Rec Mode**
- **Enter Time-Code** using the number buttons
- **Press: Set** button (yellow)
- **Press: F3** (timer-set)
- **Press: Home** button