

Cineped / Quatro Set Up

1 Structure



2 To open



- Loosen the 4 round knobs until the rosette teeth clear each other
- Align the locking teeth perfectly before attempting to tighten the 4 round knobs
- Open the 4 legs to 30° (normal position).
- Adjust 2 adjacent legs first and then adjust rest of the 2 legs
- Tighten the 4 round knobs

3 To adjust height



- Loosen the clamp by lifting the clamp handle
- Hold the leg and push down to the ground
- Lock the clamp to tighten the clamp and hold the leg in place

4 Final leveling



- Look at the bubble level and adjust the height
- 2 legs have to be adjusted at the same time

Dis-assemble

- Loosen the 4 round knobs until the rosette teeth are cleared to bring the legs back to 0° position
 - Tighten the 4 round knobs
 - Shorten the legs to '0' mark

Safety

- Safety level of leg positions on normal surface,
 - 0 degree - **Dangerous**
 - 15 " - **Dangerous**
 - 30 " - Minimum safety
 - 45 " - Safe
 - 60 " - Very safe
 - 75 " - Very safe
 - 90 " - Very safe
- Tighten the 4 round knobs and 4 clamps as tight as possible
- Make sure that 4 legs are standing rigid on the surface

For further questions
please call (310) 533-6900

www.cineped.com